

The Classé CDP-100 uses RC6 protocol for infrared communications. The following list of infrared codes can be used to program a universal or learning remote control. The Classé Remote Control uses a frequency of 56.0 kHz. Please refer to your remote control's user manual for information on how to program your remote control.

Sys code	IR code	Action
020	0	Number "0"
020	1	Number "1"
020	2	Number "2"
020	3	Number "3"
020	4	Number "4"
020	5	Number "5"
020	6	Number "6"
020	7	Number "7"
020	8	Number "8"
020	9	Number "9"
020	12	Toggle Standby/Operate
200	13	Toggle Mute/Unmute
020	14	Info (go to Status screen)
020	15	Cycle through display intensities (low/medium/high)
200	16	Volume up (volume +)
200	17	Volume down (volume -)
020	18	Cycle through time display modes
020	28	Shuffle play
020	29	Cycle through repeat modes (none, track, disc)
020	32	Go to next track (skip next)
020	33	Go to previous track (skip previous)
020	42	Scan forward
020	43	Scan backward
020	44	Play
020	48	Pause
020	49	Stop
200	56	Function key F1
200	57	Function key F2
020	58	Clear programmed play list (revert to CD's table of contents)
020	59	Program A/B
020	60	Empty playlist
020	66	Open/Close CD tray

020	68	Program mode (go to Program screen)
020	84	Menu
020	85	Home
020	88	Step up (navigate up, +)
020	89	Step down (navigate down, -)
020	90	Step left (navigate left)
020	91	Step right (navigate right)
020	92	Enter
020	120	Number "10"
200	134	Function key F3
200	135	Function key F4
020	150	Set unit in Operate (turn unit on)
020	151	Set unit in Standby (turn unit off)
200	152	Set Mute mode on (mute)
200	153	Set Mute mode off (unmute)